



Customer cleaning procedures for the 'Auswide WhiffAway Cartridge'

Do

Do spray Auswide Biocidal Cleaner over the total surface face of the wall hung or trough urinal and leave, as it will be washed over the surface face on the next timed flush

Do remove rubbish from around the WhiffAway Cartridge serrated edge ie: cigarette butts, leaves etc

Do change the WhiffAway Cartridge every three months

Do your normal scheduled cleaning within the washroom, which should include the mopping of the step or grill in a situation where there is a trough urinal

Don't

Don't use chemical blocks of any type within the urinal

Don't use bleaches or disinfectants within the urinal

Don't use acids or chemicals of any description within the urinal

Don't turn off water management system for the urinal

Don't use hot or warm water when cleaning urinals

Do not empty grey water or any other grey water that has been used to clean surfaces into the wastewater outlet of the urinal ie: buckets of dirty water that has been used to mop floors etc



Replacement procedure for the 'Auswide WhiffAway Cartridge'

Removal and Disposal of the old WhiffAway Cartridge

Place a pair of disposable gloves on your hands to remove the WhiffAway Cartridge from the urinal outlet, hold onto the top of the WhiffAway Cartridge dome and twist anti-clock wise and at the same time pull up wards to remove the old WhiffAway Cartridge

Once the old WhiffAway Cartridge has been removed, place it in the appropriate plastic recycling bin

Installation of the new WhiffAway Cartridge

Install the new WhiffAway Cartridge in the reverse of the removal procedure
As above ie: hold the dome part of the WhiffAway Cartridge and twist clock wise and at the same time push down wards to install the new WhiffAway Cartridge

Dispose of the disposable gloves into the appropriate recycling bin.